

DeoxIT®

Perfect-Straw™ Hacks

HACK #2

Info

CAIG Perfect-Straw™ Hacks. Creating Custom Attachments to the New DeoxIT® Sprays

#2 HACK - Attaching the FLEX-TIP™ to Yellow Straw!

What you need:

- Buy FLEX-TIP™ Kit from CAIG. Part No. CL-EXT-PS2
Link: <http://store.caig.com/s.nl/it.A/id.3048/f>
NOTE: Enter Promo Code FS-950 at checkout to purchase FLEX-TIP ONLY for \$1.99, plus \$1.00 S&H.
- Buy/Use any of the DeoxIT® products with the Perfect-Straw™
- Ruler
- Small X-Acto knife or straight edge razor blade.

Measure and cut the Yellow straw:

- Using a ruler, measure out 1.5" from the end of the yellow straw
- Option "B" would be to measure a longer length if you want the FLEX-TIP™ Closer to the valve – longer Red straw and shorter Yellow straw. Longer Red straw is included in CL-EXT-PS2 Kit.

Cut the Yellow straw:

- Using the knife or blade, cut the Yellow tube at 1.5"

Attach the Red straw to the Yellow straw:

- The rubber tube is very flexible
- On an angle, fit the Yellow tube into the rubber tube
- Holding close to the end of the rubber tube will help
- It helps to wiggle the tube while pushing it onto the Yellow tube
- FIRST USE:** Hold can and straw away from you and test spray a few times onto a cloth or into a trash can.

Now you have a FLEX-TIP™ for all your difficult and hard to reach applications

- Use your FLEX-TIP™ for all your hard to reach areas
- Using a SHORT Red straw or LONG Red straw – depending on the application



Home of the DeoxIT® family of
Environmentally-Safer Contact Cleaners and
Connector Enhancing Treatments
Made in USA